Wireless MultifunctionPresenter

(with 2.4GHz, Omni-directional Optical Mouse)

User's Manual

abv

Be sure to carefully read this User's Manual first for the proper use of the Wireless Multifunction Presenter and keep it for future reference.

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written prior permission of the seller.

The seller provides this document without warranty, or condition of any kind. The seller may make improvements or change in the product described in this documentation at any time.

Other product and company name herein may be the trademarks of their respective owners.

©2007 All rights reserved.

IMPORTANT SAFETY AND HEALTH INFORMATION



WARNING! RISK OF INJURY!

Laser beam can cause permanent damage to eyes. Do not look into the laser beam or shine the laser beam into your eyes, other peoples' eyes, or pet's eyes.

WARNING! RISK OF INJURY!

Keep this device away from Children. This is a working tool, not a toy or entertainment device. It should only be used by adults.

Trademarks:

Windows, Windows Media, Microsoft and PowerPoint are registered trademarks of Microsoft Corporation.
iTunes is a registered trademarks of Apple Computer, Inc.
Other trademarks and registered trademarks not listed above may be used in this manual.

Table of Contents

Chapter1 Introduction

What's the benefits 3

Overview 4

Specification 5

Package contents 5

Chapter2 Getting Started

Installation 7

Function table of each key..... 7

Application Guide 15

Chapter3 Trouble shooting

Trouble shooting 16

Chapter 1 Introduction

Thank you for choosing our Wireless Multifunction Presenter
——"Totally Control Your Presentation and PC Multimedia"

What's the benefits

More Multi-function

The Wireless multi-function Presenter combines the features of

the PowerPoint Control
Laser Pointer
2.4 Wireless optical Mouse
Multimedia Remote Control
built-in soft keyboard,
magnifier
and so on....

into one elegant device. Excellent 2.4GHz RF technology enables you to control the computer up to 15 meters/50 feet away from the receiver (connected to the USB port), the laser pointer functions up to 130 feet (40 meters) from the target.

Making your presentation easier and more successful

When making presentation, with the Wireless multi-function Presenter, you don't need to stand beside your notebook computer or have an additional person to assist you, nor do you need to aim at the USB receiver.

Having your own way to your Multimedia

When enjoying your multimedia, (Such as music, Video, Picture) the Wireless multi-function Presenter provides you with a single tool to manage your Windows Media Center (only on XP MCE and Vista system), Media Player , Real player or iTunes running on Windows®.

Easy to use

The Wireless Media Presenter is a USB plug-and-play device without any software required. The laser beam safety switch protects people from unintentional laser beam into human eyes.

Easy to carry

The patent slim RF receiver integrated with the Presenter, it can be easily put in the lightweight, protective carrying case when traveling.

Overview

● **Presentation Controls**

Smoothly navigate through Microsoft Office PowerPoint® and other presentations from up to 15 meters /50 feet away from your PC.

● **Laser Pointer**

Point out essential information during presentations with the laser pointer.

● **Media Remote for Media center or media player**

Use for multimedia presentations and control digital entertainment from the comfort of your living room sofa. Such as watching movie, listening music, playing game and browsing pictures

● **Magnifier**

You can freely Zoom in /out full screen.

● **2.4 GHz wireless Connect Technology**

Give yourself room to move—wireless mouse and keyboard products let you work without worrying about tangled wires.

● **High Definition Laser Technology**

High Definition Laser Mouse products are more precise, more responsive, and deliver smoother tracking.

● **Innovative Industrial Design**

The sleek and stylish design looks great on any desktop in your home or office.

● **On/Off Switch**

Turn your device off to extend battery life even longer.

●**USB receiver built-in Flash Memory function** (optional)

You can choose flash memory capacity from 128MB to 2GB.

● **No install any software and driver**

Model	LP05 for PowerPoint	
Function	1. 2.4G wireless optical mouse 2.Laser Pointer 3.Play from home page 4.Play from current page 5.Page up/down 6.Black Screen 7.Breaker Timer 8.Screen Zoom in/out 9.Alt-Tab 10.Esc **11.Volume up/down** **12.Media Player remote control** 13.Power Switch 14. Power save mode use	
Resolution	1000CPI	
Frequency	2.4GHz	
Distance	15M	
Flash Memory	128MB~2GB (Optional)	
USB Port	USB 1.0/1.1/2.0	
Voltage	2.4V~3.3V	
Power Supply	AAA*2	
Laser	Class II , Class III (optional)	
Weight	80g (Included battery)	
Dimension	125mm(L)*49mm(W)*27mm(H)/max.46mm(H)	
System requirements	Microsoft® Windows® 98SE/2000/ XP/ XP Media Center Edition/Vista 32bit, Vista 64bit	
Package Contents	4. Wireless Presenter *1 5. Receiver *1 6. Manual CD *1	

Chapter 2 Getting Started

Installation

1. Install battery

Open the presenter battery storey cover，and base on battery electrode sign to install battery.



（Figure 1 ）Rear for all model

2. Install USB Receiver

Please plugs into USB receiver to USB port of computer. Now you can see system information that system will display “found new hardware” on notice bar. System will automatic update driver for the USB receiver unit display success.

（Figure 2）

3. Insert CD to CD-ROM, and run ZoomIt software.

4. Turn on power switch of presenter to use.

5. Check your function list below model list base on your model

6. Explanation key icon of presenter



(Figure 3)　Left side and Top for all model

Key name	Action	Description
Mouse Left Key	Click	Mouse Left key
ON / OFF	Slide	Power Switch *presenter will sleep without any action after 3min.
Trackball	Movie	Mouse arrow



（Figure 4：**LP05** Front, Right side）

Function table of each key sort by reverse base on Figure 4

Key Icon	key name	Action	Description
	Shift+F5	Press and hold 2 sec.	Play from current page for PPT 2003 and PPT 2007
	Black Screen	Click	Black Screen in PPT status
ON/OFF	**ON / OFF**	Slide	Turn on power switch
Alt+Tab	**Alt+Tab**	Press and hold 2 sec.	Switch between programs
Esc	**Esc**	Click	Cancel the current task
	Laser Pointer	Press/Release	Generate laser bean / close laser bean
START	**Media Center**	Click	Open Media Center
	Media Player	Press and hold 2 sec.	Open Media Player
	Volume Down	Rotate Down	System Volume Down
	Next	Rotate down and hold 2 sec.	To forward program
	Play/Pause	Push	To play or pause program
	Previous	Rotate up and hold 2 sec.	To previous program
	Volume Up	Rotate up	System volume up
Right	**Right**	Click	Mouse right key
	Zoom In/out	Push	Open Zoom In/out function
	Scroll or Page Up	Rotate up	Scroll up / Zoom in
		Rotate up and hold 2 sec.	Page up
	Scroll or Page Down	Rotate down	Scroll down / Zoom out
		Rotate down and hold 2 sec.	Page down
	Breaker Timer	Click	Open Breaker Timer
	F5	Press and hold 2 sec.	Play PPT from home page

Application Guide

1. Wireless Optical trackball mouse function

2.4G wireless Optical Mouse function with all function of general mouse. You can move the trackball to move cursor. You can adjust mobile speed for cursor from control pan.

2. ZoomIt application software is suited our company's wireless presenter.

a. When you insert CD into CD-ROM, will display menu and choice "run zoomIt" to click.

When zoomit is running, you will find out the icon on the side corner of task bar.

Advise: please copy zoomit.exe file to your computer. Don't change default value.

b. zoom in or zoom out screen for all model.

a) push on wireless presenter right side to start zoom in status. Exit zoom mode with esc key or right key

Press esc key to close zoom function.

b) Now you can rotate up to zoom in on base last time. rotate down to zoom out on base last time.

c) when screen is zoom status. You can move trackball to adjust screen

c. Notes pen for only LP04

press pen key to start notes pen mode, Exit note pen mode with esc key . you must press left key and move trackball at the same time to drawing.

Press left ctrl + or arrow key to change pen width. You can change the pen color by entering drawing mode and typing "r", "g", "b", "o" or "y" for red, green, blue, orange or Yellow.

d. Break timer for LP04 and LP05

press key to open timer, exit timer with esc key.

Increase and decrease time with up or down.

3. Power Point presenter and Laser pointer function

a. Start Microsoft PowerPoint program and to play your PowerPoint file

b. Page up and page down function: you can rotate up or down on side of presenter to page up and page down.

c. Return to edit status. click **ESC** key on presenter right side

e. Laser pointer：press button to open laser bean，

release button to close laser bean。（*Caution: Don't stare into Beam*）

3. Keyboard function for LP02 and LP03

a. Press and hold key to till open on-screen keyboard in windows system

b. you can choose keyboard standard, such as 101,102,106。

c. Please move cursor to some letter, and click left key to input letter

d. Press Backspace key to delete letter

4. Browse website , picture and check mail box

a. Open internet explorer： click key to open internet browser, or open picture viewer.

b. Start Microsoft PowerPoint program and to play your PowerPoint file

c. you can rotate up or down on side of presenter to page up and page down or zoom in and zoom out. Rotate up and hold to preview slide, Rotate down and hold to Next slide.

d. Check mail box：Press and hold key to till open outlook or other default email software 。（*email software in common use:*
Outlook Express, Microsoft Outlook, Microsoft Mail, Eudora, Foxmail and so on。）

5. Media center or Media player remote control

a.**Media Center**:click button to start Media Center program， you can play movie , music, picture and so on with remote

(Note：Media Center function only Windows XP Media Center Edition, and Vista with Media Center Edtion。)

b. Media player： press and hold to till open default media player。

（ *play software in common use :Microsoft Media Player, Real Player, RealOne Player, iTune*。）

Recommend Microsoft Media Player as your default media player.

Use key on side of presenter to play/pause, volume, forward backward。

Trouble shooting

Question	How to solve
Need to install software for first use of the Presenter?	No, this is a plug and play device; you do not need to install any software.
Don't identify USB Receiver	Please confirm USB port is available.
Don't zoom in screen	Please confirm software that zoomit is running
Don't Notes pen	Please confirm software that zoomit is running
Don't Break timer	Please confirm software that zoomit is running
Don't play ppt	Please confirm software that power point is running
Don't open Internet Browser	Restore Internet Browser to default value
Don't open email program	Restore email program to default value
Don't open Media Center	Please check your system whether it has Media Center
Don't open soft keyboard	Please check your system whether it installed on-screen keyboard. Or please copy on-screen keyboard from CD to windows\system32 folder
Don't open magnifier	Please check your system whether it installed magnifier. Or please copy magnifier from CD to windows\system32 folder
No Laser Bean	Replacing a new battery